# SPLIT-CORE CURRENT TRANSDUCER



The Split-core Current Transducer, V Series, is designed for energy management, with a convenient connection to electronic submeter. It may also be applied for current measurement in a system of distributed power line carriers (PLCs) or remote controls such as SCADA software for automation and supervision. Other applications include security and condition monitoring, load monitoring, in protection systems, and for predictive maintenance of conveyers, pumps or HVAC motors.

#### APPLICATIONS

- HVAC & Pumps
- Refrigeration
- Small Industrial Motors
- Fans
- Lighting

#### BENEFITS

- Small-size, light-weight
- Simple Installation
- Over-Voltage protection circuit is installed.



### **FEATURES**

- Nylon-spring, output-terminal, secure locking hinge, one-touch structure makes easy to install to the existent equipments such as a power distribution boards.
- Isolated plastic case recognized according to UL94-V0
- UL/EN 61010-1 certified

## **HOW TO USE**



※ Please refer to "Split-core Current Transformer Installation Guide" for further details.

# A CAUTION: DANGER A

- HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH • In order to guarantee safe operation of the transducer, please read
- and understand the instructions thoroughly. For your reference, see NFPA 70E in the USA, or applicable local codes.
- Certain parts of the module may carry hazardous live voltage when the transformers being operated (e.g. primary conductor, power supply).
- This equipment must only be installed and put into operation by qualified electrical personnel or appropriately trained individual.
- Before servicing the CTs, disconnect all sources of power and use a properly rated voltage sensing device to check if the power is off.
- Make sure to install the transducer only on insulated conductors.
- Do not depend on this product for voltage indication
- Use the product in a Pollution Degree 2. A Pollution Degree 2 environment must control conductive pollution and the possibility of condensation or high humidity. Regard the enclosure, thermal properties of the equipment, the proper use of ventilation and the relationship in surroundings.

# 

- If you impact the core contact surface, internal core material could be damaged.
- Please use only the original output screws. Not recommanded to replace it with anything else.
- Customizing output lead wire
- This product is not intentionally made for safety applications.
- The installer is responsible for conformance to all applicable codes.
- Ignoring the warnings could result in serious injury and/or cause damages.
- Do not install and use this transducer in hazardous or classified areas.
- If this product is used in a way not specified by the manufacturer, the protection offered by the product may be impaired.
- No responsibility is taken by J&D Electronics for any consequences arising by not following this material properly.



### SPECIFICATION

(F=50/60Hz)

Model	JC10F-XXX-V / ø10				
Current Range(Arms)	5/ 10/ 20/ 25/ 50       100%(Continuous), 150%(1 mim.)       0~5V DC (Average)/0- Rated Current, 7.5V DC Limiter built-in       ±2% FS. Dynamic Range 1:100(50/60Hz Sinewave)       7kΩ/ 8.5 kΩ/ 6.8 kΩ/ 6.8 kΩ/ 6.2 kΩ				
Max. Allowable Current					
Output					
Accuracy / Linearity					
Output Impedance					
Sensor Supply Voltage	Self-Powered				
Response Time	300ms   Within 5% of Output Voltage   2 x M3-Screw, with Terminals cover				
Output Ripple Voltage					
Output Terminals					
Insulation Category	CATIII				
Operating Condition	-20°C~+50°C, ≤85%RH, No condensation, In-house & Any direction installable				
Storage Condition	-30°C~+90°C/ ≤85%RH, No condensation				

## OUTPUT VOLTAGE DATA / OUTPUT IMPEDENCE



	СТ
+ \$1	
S1	S2

	JCØF-XXX-V						
Std.	Ø	10					
Model	XXX	5	10	20	25	50	
Output Impedance(kΩ)		7	8.5	6.8		6.2	

### DIMENSIONS



						Unit . mini
Model	А	В	С	D	E	Ød
JC10F	50	38	23	26	14.5	10

APPLICATIONS



